


REFRIGERATOR/FREEZER UPRIGHT

UKFC36RX1 / UKFC40RX1



 **smeg**

Please read these instructions carefully before putting the appliance into service. They are brief and contain only information which will help you to obtain the best performance from the appliance.

Take care of all accessories supplied with the appliance.

CONTENTS

1. Before starting the refrigerator/freezer.
2. How to use the appliance.
3. General advice on the use of the appliance.
4. Maintenance.
5. Has the appliance stopped working?
6. Safety.
7. Technical data.
8. Installation.
9. Change of hinge side.

1. BEFORE STARTING THE REFRIGERATOR/FREEZER

Check that the cabinet is undamaged. Please report any transport damage **immediately** to your dealer.

Wash the cabinet and inner lining with a mild unscented detergent and wipe it dry. Do not use abrasive scouring powder, steel wool or similar.

Connection to the electricity supply: See head (7) and (8).

2. HOW TO USE THE APPLIANCE

Operating panel: See fig. (1) page 7.

1. Lamp for the refrigerator section.
2. Thermostat knob for the refrigerator section.
3. Thermostat knob for the freezing section.
4. Indicator for the connection to the electricity supply (green).
5. Indicator for deep-freezing (yellow).
6. Button for deep-freezing.
7. Thermometer for the freezing section.
8. Warning lamp.

The thermostat knob is adjustable from 0 (stop) to 7 (coldest). Find the position of the thermostat which gives you the desired temperature. Start at position 4.

The refrigerator section

Never store hot foodstuffs in the cabinet and remember always to wrap up the foodstuffs.

The evaporator of the refrigerator section is automatically defrosted. The defrost water is led to a tray on top of the compressor where it evaporates.

The freezing section

Operating panel. See fig. (1) page 7.

Deep-freezing: Push the button (6). The yellow indicator will then glow. It stops glowing when the button is pushed anew. When the quantity of foodstuffs to be frozen is larger than 3 kg the button for deep-freezing should be pushed about 24 hours before the desired freezing.

The button is pushed anew when the foodstuffs are frozen.

It is important that the deep-freezing takes place as quickly as possible. Therefore, the temperature of the foodstuffs should be no higher than room temperature.

Otherwise follow the advice given in handbooks on deep-freezing and the choice of packing material.

Place the foodstuffs so that they obtain maximum contact with the freezing shelf. Open the door only when necessary. The lamp of the alarm knob, fig. (1), page 7, indicates whether the acoustic alarm is on. If the lamp is lit the acoustic alarm will sound if the temperature is too high.

Please note that the water ices, if consumed immediately after removal from the freezer compartment may result in a freezer-burn, and they should be allowed to warm slightly before consumption.

Defrosting

The foodstuffs cause frost to be formed. A thin layer of frost does not affect the performance of the freezer.

Loose frost may be removed carefully with a plastic or wooden scraper. **Never** use a knife or other sharp tools. When the layer of frost on the shelves is 5-10 mm the freezer should be defrosted.

Note: The layer of frost on the front edge of the top freezing shelf may grow slightly thicker.

Do like this:

Switch off the freezer.

Take out the foodstuffs and wrap them in newspaper, a blanket or similar and store them as cold as possible.

Place a bowl with hot but not boiling water in the freezer.

Fold out the draining spout, mount the enclosed extension and place a bowl under it, fig. (3) page 7.

Wipe the cabinet when the frost has disappeared.

3. GENERAL ADVICE ON THE USE OF THE APPLIANCE

The shelves in the refrigerator section can be moved, fig. (5) page 7.

The door rack and the butter- and cheese-boxes are also movable, fig. (2) page 7.

The freezing shelf cover should be closed.

The covers are opened by pulling, fig. (6) page 7.

To remove the baskets lift them over the stop pins, fig. (4) page 7.

If the cabinet is not to be used for more than 48 hours the doors should be left open to avoid ill smells.

The appliance is equipped with a high-quality skin condenser.

Therefore, a slight heating of the sidewalls is quite normal.

Lighting

This appliance is equipped with a device which causes the light to switch off if the door is open / left ajar for abnormally long time.

When the door has been closed for a couple of minutes, the device is cut off and the light switches on in normal way again.

Important!

In case of damage to the power cord it must be replaced by a power cord of corresponding type, available from the manufacturer or his service representative.

4. MAINTENANCE

Only use an unscented detergent when cleaning the cabinet inside.

Switch off the appliance and pull out the plug when cleaning the cabinet.

The skirting board can be removed to facilitate a vacuum cleaning of the floor.

See fig. (1) page 6.

Remember to clean the drain in the refrigerator section also.

DISPOSAL OF THE APPLIANCE

The appliance contains recyclable materials. When disposing of the appliance, please contact the technical administration or other appropriate authority in your municipality. They can inform you of the collection and recycling measures used in the municipality.

5. HAS THE APPLIANCE STOPPED WORKING?

Before calling a repairman, check that the plug is properly plugged into the wall socket.

The fuse is intact.

The power has not been cut off.

All controls are correctly set.

The quantity of foodstuffs in deepfreezing is not too large.

Switch off the cabinet for 15 minutes (for instance at the thermostat). Switch it on again and after 5 minutes check whether frost has formed on the evaporator.

Do not open the cabinet when unnecessary. If the break appears to stretch over a longer period (over 12 hours) store the foodstuffs, if possible, in another freezer.

Most foodstuffs, if thawed on the outside but otherwise hard, can be re-frozen.

6. SAFETY

Do not store explosive substances in the refrigerator section, such as gas, cigarette lighters, petrol, ether or similar.

Scrapped cabinets may become dangerous to children at play. Therefore, remove the doors or place the scrapped cabinet in such a way that children cannot enter it.

Never store liquids with carbon dioxide in the freezing section.

7. TECHNICAL DATA

This appliance meets the provisions of the following directives:

89/336/EEC (electromagnetic compatibility), 73/23/EEC (electrical equipment designed for use within certain voltage limits) as amended.

Household appliances sold in the EU also meet 96/57/EEC (energy efficiency requirements) as amended.

The rating plate, which is placed either at the back or inside the appliance, see fig. (7) page 7, provides various technical information as well as type and serial number.

8. INSTALLATION

See drawings (1) and (2) page 6.

Install the cabinet in a dry place and so that it is not exposed to direct sunlight or any other source of heat.

Place the cabinet in a level position. This is easily achieved by adjusting the adjustable feet at the front edge of the base. The cabinet should not rest against a wall on its hinged side. When placing the cabinet on a carpet or on a wooden floor, the placing should be checked after a while to see whether the unit has „subsided“ into the soft flooring.

The cabinets can be built in or put side by side, see fig. (2b) page 5.

KF models put side by side with other models require a distance of 2 inches between the appliances.

For sufficient airflow around the cabinet it is necessary to have a 4 inches high air duct right above the appliance, see fig. (2a) and (2b) or an air duct that leads the air up over the top cupboard, see fig. (2c).

Make sufficient space for door opening as to draw the baskets out, see fig. (2e).

The dimensions for building in are noted on the drawings.

It is safest to place the earthed wall socket above the appliance and at least 2.0 m above the floor.

Any local installation rules for appliances of this kind must be observed.

During a storm the electricity supply might be cut off.

You should be aware of this when installing the appliance in weekend cottages or elsewhere where you would not immediately observe that the power has been cut off.

Construction and details in the accessories are subject to alteration without previous notice.

If the cabinet is to be adjusted:

See drawings (1) page 6

Take hold of the front panel with both hands. Then lift up the front panel and turn out the bottom part.

Adjust the tilt of the unit

See drawings (1) page 6

by turning the adjustable feet with a 13 mm spanner.







Fig 1.



9





Fig 2.



min. 625




Fig 1.




Fig 2.




Fig 3.




Fig 4.




Fig 5.




Fig 6.






Fig 7.

9. CHANGE OF HINGE SIDE

- 1) Dismantle the top hinge. This one is to be used later as top hinge at the opposite side. Lift off the top door.




- 2) Dismantle the middle hinge. Lift off the bottom door. Mount the hinge screws again.




- 3) Remove the kick panel.


- a) Only for appliances with a door closer on the bottom door. The door closer is moved to the second hole.




- b) The bottom hinge is dismantled at the 3 screws. The hinge is turned 90° and mounted on the opposite side.




- 4) Dismantle the screws in the middle of the new hinge side. Mount the bottom door and screw on the middle hinge.




- 5) Adjusting the bottom door: Loosen the 3 screws in the bottom hinge and push the bottom hinge to the required side. Tighten the screws and mount the kick panel.



- 6) The kick panel is mounted and the hole plugs are mounted on the opposite side.



- 7) Adjustment of the top door: loosen the screws in the hinge above the door, loosen the hinge above the door and turn the hinge to the wanted side. Tighten the screws.



- 8) Move the handle.

